

# **Installation Instructions**


### AURA-2432-RT






## **Installation Instructions**

### AURA-2432-RT



#### INSTALLATION INSTRUCTIONS



of the hanging cleat with a pencil.

2>The bottom screw positioning is measured based on the hanging cleat edge The screw position is parallel and centered, and the hanging cleat center is downward. Pay attention! When positioning the bottom screw position, please use a level ruler to level the vertical direction. As shown in the above diagram.

